


Montageanleitung Assembly instruction
drylin®





ZLW-1040




Linearmodule für manuelle und elektrische Verstellungen Linear modules for manual and electric adjustments


①	ZSY-104001	1x
②	NOR-10601	4x
③	NOR-10703	2x
④	ZSY-104002	2x
⑤	WJUM-11-10	4x
⑥	ZSX-104001	1x
⑦	ZR-104001-XX	1x
⑧	NOR-10412	8x
⑨	NOR-20602	8x
⑩	NOR-10614	4x

⑪	SAXT-104002	2x
⑫	ZTY-104035	4x
⑬	JTEM-10	9x
⑭	NOR-20901	4x
⑮	SAWT-104001	1x
⑯	SAXT-104003/04	1x
⑰	SAXT-104001	1x
⑱	SAWT-104002	1x
⑲	NOR-10604	6 x







1




2




3




4




5




6




7




8




9





10







12





13





14















18




19








Alle 4 Schrauben gleichmäßig herausdrehen!
Screw out all 4 screws evenly!





21





23





iglus® GmbH
Spicher Str. 1a
51147 Köln Cologne
Tel. +49 2203 9649-145
Fax +49 2203 9649-334
info@iglus.de
www.iglus.de
www.iglus.eu

© iglus® GmbH

Herausgeber ist die iglus® GmbH, Deutschland
Published by iglus® GmbH, Germany
MAT0074123.25 Stand Issue 03/2018
Technische Änderungen vorbehalten
Subject to technical alterations